Installation instructions

Main Control Card (EN)



(VIG-MCC-EN) for EN54 Vigilon 4-loop panel with zone LEDs


This Main Control Card is compatible with EN Vigilon Panels and Vigilon inner doors supplied after 15th February 2005.

Vigilon panels using VIG-MCC-EN Main Control Card are compatible with S-Quad range of sensors.

The Vigilon inner doors are identified by a label that reads:

THIS DOOR REQUIRES VIG-MCC-EN S/W 2211-143 VERSION 4.30 OR GREATER

The Main Control Card is supplied as standard in all EN version of Vigilon panels supplied after 15th February 2005.



This MCC MUST NOT be installed in BS version of Vigilon or 34000 Fire panel.

Technical data

Overall size	157mm height x 100mm width
Weight	96g (approximate)
Lithium Battery	CR2032 3V cell. Replace only with the same or equivalent type battery. Dispose of used batteries according to the manufacturer's instructions.
Operating temperature	0°C to 45°C
Storage temperature	-10°C to 55°C
Relative humidity (non condenscing)	up to 90%


Compatibility

(supplied parts highlighted)

	Identifications	Compatible control card
Vigilon Inner door EN54 without zone LEDs	□ No Zone LEDs	VIG-MCC-UPGR (V4.30 and above) VIG-LCC
Vigilon Inner door EN54 with zone LEDs supplied up to 15th February 2005	☐ Zone LEDs ☐ 6 LEDs on control indication facia	VIG-MCC
Vigilon Inner door EN54 with zonal LEDs supplied after 15th February 2005	 ☐ MCC compatibility notice on inner door ☐ Zone LEDs ☐ 12 LEDs on control indication facia 	VIG-MCC-EN (V4.30 and above)

Battery connection


The MCC has a battery that is disconnected by means of a factory fitted sleeve. The sleeve must be removed before the MCC card is installed into the backplane.



Once the battery sleeve is removed from the MCC, the card MUST NOT be placed on a metal surface as this may result in damage to the components on the card.

Installing the MCC

The MCC must be fitted into the LCC slot P1 on the backplane. The ribbon cables from the display keyboard card (DKC) should then be connected in the manner shown below.



Novar Systems Limited reserves the right to revise this publication from time to time and make changes to the content hereof without obligation to notify any person of such revisions of changes.

CENT	Hamilton Industrial Park, Waterside Road, Leicester LE5 1TN, UK		Website: www.gent.co.uk
GENI	Telephone +44 (0) 116 246 2000		Fax (UK): +44 (0)116 246 2300